

AT Command Overview



INSYS Modem
144/336/56K 4.0

Copyright © June 05 INSYS MICROELECTRONICS GmbH

Any duplication of this manual is prohibited. All rights on this documentation and the devices are with INSYS MICROELECTRONICS GmbH Regensburg.

Restrictions of guarantee

This handbook contains a concise description. The compilation of the text has been made with the utmost care. Despite all efforts, there may be deviations compared with the actual functions. No guarantee can therefore be given for the accuracy of the contents. We can neither take over a legal responsibility nor any liability for incorrect information and their consequences. Suggestions for improvements and comments are gladly accepted.

Trademarks

The use of a trademark not shown below is not an indication that it is freely available for use.

MNP is a registered trademark of Microcom Inc.

IBM PC, AT, XT are registered trademarks of International Business Machine Corporation.

INSYS ® is a registered trademark of INSYS MICROELECTRONICS GmbH.

Windows™ is a registered trademark of Microsoft Corporation.

Publisher:

INSYS MICROELECTRONICS GmbH

Waffnergasse 8

D-93047 Regensburg, Germany

Phone: +49 (0)941/58692-0

Fax: +49 (0)941/563471

e-mail: insys@insys-tec.de

Internet: <http://www.insys-tec.de>

Subject to technical changes as well as correction.

Date: June 05

31-22-03.035 english

1	SYNTAX OF STANDARD AT COMMANDS	1
1.1	RESPONSES FOR NORMAL DATA COMMUNICATION	2
1.2	OVERVIEW AT COMMANDS	2
2	S REGISTRY	26
2.1	OVERVIEW S REGISTRY	26
2.2	DESCRIPTION S REGISTRY	27
3	COUNTRY CODES (ONLY 56K)	37
3.1	VERSION FOR STANDARD COUNTRIES	37
3.2	VERSION FOR EXTENDED COUNTRY GROUP	38
3.3	COUNTRY CODES FOR BOTH VERSIONS	38

1 Syntax of Standard AT Commands

The modem guideline V.25ter is applicable with regard to the time sequence of interface commands. The **AT** standard is a line-oriented command language. Each command consists of three elements: Prefix, body and end character.

The **prefix** always consists of the letters “**AT**”; the only exception is the command “**A/**”.

The **body** consists of individual characters which are described in the following chapter. The body consists of a name and pertinent values, if applicable.

Syntax:

<expression>	Input of a parameter
<Pause>	Means a waiting period of one second
[expression]	Optional input of a parameter

The factory settings are marked with “(default)”.

The standard end character is “return” (oDh) or “<CR>”. “Return” may not be entered after “****” or “+++”.

Commands can be grouped to one command line. Space characters between the individual main parts are ignored. The commands can be categorized as follows:

- Basic instruction set
- Extended instruction set (Main part starts with “+” or “^”)

The commands are acknowledged with “OK” or “**ERROR**”. A command that is being edited will be interrupted by any further incoming character. Therefore, the next command must wait for acknowledgement to avoid the deletion of the current command.

Additional overviews for pure voice function commands are available as separate documents for INSYS Modem 144/336 and INSYS Modem 56 k at INSYS MICROELECTRONICS.

1.1 Responses for Normal Data Communication

Response	Code	Type	Meaning
OK	0	Final	Command executed, no error
CONNECT	1	Progress message	Connection established if parameter setting X=0
CONNECT[<text>]		Progress message	Connection established if parameter setting X=0 <text>: E.g. 'connect 9600'. The data transmission rate is then 9.600 bit/s.
RING	2	Non-synchronized	Ring tone recognized
NO CARRIER	3	Final	Connection not established or disconnected
ERROR	4	Final	Invalid command or command line too long
NO DIAL TONE	5	Final	No dial tone, connection setup not successful, wrong operating mode
BUSY	6	Final	Remote terminal busy
NO ANSWER	7	Final	Timeout for connection setup

1.2 Overview AT Commands

Command	Description
AT**	<u>Start of the flash load function</u>
ATA	<u>Answer mode</u> The modem is switched into response mode. This is only effective in Germany, if the connected phone goes off-hook or if a call comes in.
A/	<u>Repeat the last command</u> The last command is repeated.
AT\A<n>	<u>Select maximum MNP block size</u> Define maximum block size for error corrected MNP transmissions. AT\A0 64 characters AT\A1 128 characters (default) AT\A2 192 characters AT\A3 256 characters
AT*A<n>	<u>Automatic call acceptance on/off</u> AT*A0 Call acceptance is blocked, irrespective of S0 AT*A1 Call acceptance according to S0 (default)
AT%A	<u>Simple alarm release</u> Releases a simple alarm. Corresponds to an activation of the alarm input. The response occurs after the signal has been sent with "OK" or "ERROR". Note: see also AT*V

Command	Description
AT%A<n>	<u>Triggers a pulse alarm</u> Triggers a pulse alarm. Corresponds to an activation of the alarm input with n pulses from 0.3 .. 2 seconds. n=1..10. The response occurs after the signal has been sent with "OK" or "ERROR". Note: see also AT*V<n>
AT&A<n> <i>(only for INSYS Modem 56k)</i>	<u>Selective Call Answer On or Off</u> AT&A1 Switches the selective call answer on AT&A0 Switches the selective call answer off (default) Input of permitted numbers with AT*N The AT&A setting is saved in AT&W .
ATB<n>	<u>CCITT or Bell for connections with 300 bit/s</u> ATB0 Select CCITT modulation format (default) ATB1 Select Bell modulation format
AT\B<n>	<u>Send "break" to the other modem</u> For connections that were not error corrected the modem sends a break signal to the other modem. The length of the signal is: the specified parameter times 1/10 of a second. For error corrected connections, the modem sends a break signal according to the active error correction protocol without considering a parameter specification. If no connection is established or if a fax connection is active, an error message is displayed. AT\B1 1/10 second break signal to AT\B9 9/10 second break signal
AT%B<n>	<u>Switch key abort on and off during connection</u> AT%B0 Key abort is active. Each character on the Tx line will result in an interruption of the connection setup. (default) AT%B1 Key abort is deactivated. The connection setup cannot be interrupted manually. A connection setup can only be interrupted via DTR drop, Cancel (NO DIALTONE , BUSY) or Timeout (NO CARRIER). (S-Registry 36 Bit 6) (Only INSYS 144/336: The deactivation can take up to 3 seconds. During this period no data transmission is possible).
AT%C<n>	<u>Enable data compression</u> Enable/disable a data compression type The modem can only perform data compression for error corrected connections. AT%C0 No data compression enabled AT%C1 MNP 5 data compression enabled AT%C2 Enable V.42bis data compression AT%C3 Enable MNP 5 and V.42bis data compression (default)

Command	Description
AT*C	<u>Remote configuration password</u> This password secures the remote configuration as well as incoming data connections (see AT*P) and security callback. OLD PASSWORD requires the old password (default setting: QWERTY). Wrong input leads to ERROR . NEW PASSWORD Enter the new password with 6 to 12 characters. CONFIRM repeat the new password. Wrong input leads to ERROR . OK The password is immediately stored in the EEPROM.
AT*C1	<u>DTMF PIN</u> The PIN consisting of 4 characters secures the access to DTMF switching commands. OLD DTMF-PIN requires the old PIN (default setting: 0000). Wrong input leads to ERROR . NEW DTMF PIN Enter the new PIN (all characters are allowed – use only DTMF characters: “0..9”, “A..D”). CONFIRM repeat the new PIN Wrong input leads to ERROR . OK The PIN is immediately stored in the EEPROM.
AT&C<n>	<u>DCD (CT109) behavior</u> Behavior of the RS232 DCD output of the modem. AT&C0 DCD always on AT&C1 DCD follows the carrier signal of the phone line (default)

Command	Description
ATD<n>	<p><u>Dial</u></p> <p>The modem goes off-hook and dials according to the dialing string transmitted via the ATD command. After it dialed, the modem attempts to establish a connection. If the ATD command was performed without a dialing string, the modem goes off-hook and attempts to connect to the other modem (without dialing). The behavior of the modem depends on the activation of the line current recognition (see ATX command).</p> <p>The execution of the ATD command also depends on when the last dialing attempt was performed.</p> <p>In the mode FCLASS=0 the modem acts like a data modem. It attempts to connect to another data modem. This attempt is repeated until the waiting period that was specified in the S7 registry has expired.</p> <p>If this period is exceeded, the modem hangs up and the following error message appears: NO CARRIER is displayed.</p> <p>In the modus FCLASS=1 or =2 the modem acts as a fax modem. It attempts to connect to another fax or fax modem. (The modem goes into receive status HDLC V.21 channel 2, as if the command AT+FRH had been executed.)</p> <p>The following characters may be transmitted as parameters (brackets, punctuation marks, spaces and semicolons are ignored):</p> <p>0 to 9 The digits from 0 to 9</p> <p>* The asterisk: Only for tone dialing</p> <p># The hash: Only for tone dialing</p> <p>A-D The inband signaling characters A, B, C, D</p> <p>P Pulse dialing mandatory: Pulse or tone dialing is required according to the region.</p> <p>T Tone dialing mandatory: Pulse or tone dialing is required according to the region.</p> <p>W Wait for dialing tone: The modem waits for the dialing tone before it starts to dial. If no dialing tone was detected within the period specified in the S6 registry, the modem hangs up and an error message is displayed.</p> <p>@ Waiting for silence: The modem waits at least five seconds for silence in the line, before it executes the next character from the parameter string. If this five-second silence cannot be detected and the abort period in the S7 registry has not been exceeded, the modem terminates the connection displaying the message: NO ANSWER.</p> <p> If busy signal recognition was activated, the modem terminates the connection displaying the message: BUSY.</p> <p> If a response tone from the other modem is received during the waiting period, a connection is established.</p> <p> Dial tone delay: The modem performs a dial tone delay before it executes the next character of the parameter string. The delay length is defined in the S8 registry.</p>

Command	Description
ATD<n> CONTINUATION	<p>L Last number re-dialing.</p> <p>; Return to the input mode after dialing. Is attached to the end of the dialing string. Causes the modem to return to the input mode after reaching the character “;” (message: OK). This enables the input of AT commands even with a receiver off-hook. The additional AT commands can follow in the same input line after the “;” or they can be transmitted to further input lines. The ATH command will abort the connection and the receiver is hung up.</p> <p>S=n Dialing the n-th number from the number pool, which was set up with the AT&Z command.</p> <p>! Flash. If the character ! is a part of the dialing string, the modem will hang up within the time determined in S29 and then goes off-hook again.</p> <p>^ Suppresses the sending of a ringing tone.</p> <p>ATD12345; The semicolon (;) causes the return to the input mode after dialing.</p> <p>Factory setting: Ringing tone is sent for fax operation. No ringing tone for data operation.</p> <p>() Are ignored: They are just used as an outline.</p> <p>- Are ignored: They are just used as an outline.</p> <p>, , Space characters are ignored: They are just used as an outline.</p> <p>Examples:</p> <p>ATD12345 Dial the phone number 12345</p> <p>ATDP12345 Dial the phone number 12345 with the pulse dialing method</p> <p>ATDT12345 Dial the phone number 12345 with the tone dialing method</p> <p>ATX3D0W12345</p> <p>For PBXs, which connect to the exchange line using the prefix 0 (or 9): First, blind dialing is activated with :X3 (see “ATX3” command), to be able to dial a leading 0 without hearing a dialing tone. After the 0 has been dialed via :D0 , dialing tone recognition can be switched on again using the parameter :W . The modem thus waits for the dialing tone and continues with the rest of the dial-up (via :12345) only after hearing the dialing tone. Waiting for the dialing tone may be omitted. In this case, the dialing command is ATX3D012345.</p>

Command	Description														
AT&D<n>	<p><u>DTR (CT108/2) behavior</u></p> <p>DTR (CT108/2) behavior - Monitoring on/off transitions of the RS232 DTR line of the PC.</p> <p>AT&D0 DTR is ignored. Allows the operation with PCs that do not run DTR.</p> <p>AT&D1 A DTR on/off transition causes the modem to react as if it had received an abort sequence +++ . The modem switches to the input mode without hanging up.</p> <p>AT&D2 A DTR on/off transition causes the modem to hang up. Going off-hook automatically is not possible (default).</p> <p>AT&D3 A DTR on/off transition causes the modem to perform a reset as if an ATZ command had been executed. A preceded AT&Y command decides if either the default 1 or 2 is loaded.</p>														
AT\D<n>	<p><u>DTMF mode activation/deactivation</u></p> <p>AT\D1 Switch on DTMF mode</p> <p>AT\D0 Switch on DTMF mode (default)</p> <p>When the DTMF mode is activated, the modem will be set into DTMF mode for incoming calls. After the signal OK, the modem requires the input of the 4-digit PIN. The PIN input is acoustically acknowledged.</p> <p>The following commands can be performed via the phone keys:</p> <table> <tr> <th>Key</th><th>Meaning</th></tr> <tr> <td>0*</td><td>Terminate connection</td></tr> <tr> <td>1*x</td><td>Control switch output 1</td></tr> <tr> <td> x:</td><td> 1: Set switch output 1 0: Reset switch output 1 Return: "OK" </td></tr> <tr> <td>2*x</td><td>Control switch output 2</td></tr> <tr> <td> x:</td><td> 1: Set switch output 2 0: Reset switch output 2 Return: "OK" </td></tr> <tr> <td>3*x</td><td> Query of the two alarm inputs: Both alarm inputs are output as HIGH or LOW in succession. Return: "OK" – Status input 1 – Status input 2 </td></tr> </table>	Key	Meaning	0*	Terminate connection	1*x	Control switch output 1	x:	1: Set switch output 1 0: Reset switch output 1 Return: "OK"	2*x	Control switch output 2	x:	1: Set switch output 2 0: Reset switch output 2 Return: "OK"	3*x	Query of the two alarm inputs: Both alarm inputs are output as HIGH or LOW in succession. Return: "OK" – Status input 1 – Status input 2
Key	Meaning														
0*	Terminate connection														
1*x	Control switch output 1														
x:	1: Set switch output 1 0: Reset switch output 1 Return: "OK"														
2*x	Control switch output 2														
x:	1: Set switch output 2 0: Reset switch output 2 Return: "OK"														
3*x	Query of the two alarm inputs: Both alarm inputs are output as HIGH or LOW in succession. Return: "OK" – Status input 1 – Status input 2														

Command	Description
AT\D<n> <i>CONTINUATION</i>	<p>Acoustic response</p> <p>Description</p> <p>Short long tone – short pause ok Short high tone</p> <p>Long low tone ERROR invalid command, wrong PIN</p> <p>High long tone LOW Alarm input active HIGH Alarm input inactive</p> <p>If no DTMF tone is entered for more than 25 seconds, the modem will automatically disconnect.</p> <p>If the INSYS modem recognizes the call tone of a modem that wants to establish a connection, it will immediately switch to data mode.</p>
AT+DS<n> <i>(only for INSYS Modem 56k)</i>	<p><u>Activate/deactivate V.42bis data compression</u></p> <p>AT+DS=0 Deactivates V.42bis data compression AT+DS=3 Activates V.42bis data compression (default)</p>
AT+DS44=<n> <i>(only for INSYS Modem 56k)</i>	<p><u>Activate/deactivate V.44 data compression</u></p> <p>AT+DS44=0 Deactivates V.44 data compression AT+DS44=3 Activates V.44 data compression (default)</p>
ATE<n>	<p><u>Command entry Echo</u></p> <p>This command toggles the responses, which the modem creates as reactions from PC commands (Echo).</p> <p>ATE0 Switch off Echo ATE1 Switch on Echo (default)</p>
AT%E<n>	<p><u>Automatic Retrain</u></p> <p>When transmission problems occur, the modem executes a retrain procedure. After three unsuccessful attempts, the modem will hang up.</p> <p>AT%E0 Retrain not allowed AT%E1 Retrain allowed AT%E2 Fall back, fall forward allowed (default) AT%E3 Fast fall back, fall forward. Is not supported by all modem types.</p>
AT*E	<p><u>Terminate remote configuration</u></p> <p>AT*E terminates a remote configuration.</p>
AT&F	<p><u>Loading the default factory settings</u></p> <p>The modem loads the default factory setting from the internal, nonvolatile memory. This puts the modem into a defined basic state. AT&F also resets a part of the S registry.</p>

Command	Description
AT\G<n> <i>(only INSYS Modem 144/336)</i>	<u>Data flow control between modems (XON/XOFF)</u> <p>Disables or enables data flow control for connections that were not error corrected. The data flow control is regulated by the ASCII characters XON and XOFF. The modem interrupts the data transmission after receiving an XOFF character and continues the data transmission after receiving an XON character. Error corrected transmissions use their own type of data flow control.</p> <p>Therefore, a possible default data flow control setting is ignored within error corrected connections. During videotex operation, the XON/XOFF data flow control must be switched off.</p> <p>AT\G0 Switching off the modem/modem data flow control (default)</p> <p>AT\G1 Switching on the modem/modem data flow control with XON/XOFF</p>
AT+GCI <i>(only for INSYS Modem 56k)</i>	<u>Set country code</u> <p>The command AT+GCI allows the customization of the modem for different countries. Factory setting: AT+GCI=FD to Europe (CTR21).</p> <p>Please find a detailed list of the countries that can be set in Chap. 3.</p> <p>Note: Please note that all country settings will result in ALL modem settings being reset to the factory settings (such as AT&F&W). Therefore, please select a country profile first and adjust the settings afterwards.</p>
ATH	<u>Disconnect connection</u> <p>The modem hangs up.</p>
AT*H<n>	<u>Declaration of the connection protocol speed (MNP 10)</u> <p>AT*H determines the speed that is used to exchange the declarations during the MNP10 connection setup before the modems enter the MNP 10 mode.</p> <p>AT*H0 The connection setup takes place with the highest possible speed (default)</p> <p>AT*H1 Connection setup takes place with 1,200 bps</p> <p>AT*H2 Connection setup takes place with 4,800 bps</p>
ATI<n>	<u>Identification</u> <p>The modem sends an identification to the PC, according to the following parameter:</p> <p>ATI0 Product code</p> <p>ATI1 Previously calculated EPROM checksum</p> <p>ATI2 Calculation of the EPROM checksum and comparison with the previously calculated checksum stored in the EPROM. OK for correct comparison.</p> <p>ATI3 Number of firmware version in the EPROM</p> <p>ATI4 Modem version number</p> <p>ATI5 Country code parameter (Germany = 006/Europe = 253)</p> <p>ATI6 Version number and revision of the “data pump”</p>

Command	Description
AT*I	<u>Manual query of the alarm input</u> Response <Input 1>,<Input 2> The response provides the values “1” for inactive (open) and “0” for active (connected to ground)
AT+IPR=<n> <i>(only for INSYS Modem 56k)</i>	<u>Determine baud rate</u> The command AT+IPR switches the automatic baud rate detection on and off. AT+IPR=0 Activates the automatic baud rate detection (default) AT+IPR=<n> Sets the modem to the fixed baud rate n. The following baud rates are supported: 300, 1,200, 2,400, 4,800, 9,600, 19,200, 38,400, 57,600 and 115,200. The setting AT+IPR is not saved with AT&W , which means that in order to inactivate auto bauding, the command AT+IPR must be sent to the modem every time it is switched on.
AT&K<n>	<u>Select data flow control between the PC and the modem (handshake)</u> Fax operation default is RTS/CTS. AT&K0 No data flow control AT&K3 Select data flow control RTS/CTS (default) AT&K4 Select data flow control XON/XOFF AT&K5 Select transparent data flow control XON/XOFF AT&K6 Select RTS/CTS and XON/XOFF data flow control AT&K8 Activates the controlled half duplex operation on the serial interface for RS485. In this mode, the CTS signal is deactivated (high), while the INSYS Modem sends data at the serial interface. Thus, the CTS signal can be used as driver release signal for a RS485 driver. The polarity can be set with AT&R .
AT-K<n>	<u>Extended MNP functions (MNP 10)</u> This command determines if a V.42LAP-M connection can be switched to a MNP 10 connection AT-K0 Disables switching from V.42 LAP-M to MNP 10 (default) AT-K1 Enables switching from V.42 LAP-M to MNP 10

Command	Description
AT\K<n>	<p><u>Break control</u></p> <p>The modem reacts to a break (receive path off for a certain amount of time), which it receives from another modem or from the PC, or from the command AT\B according to the parameters.</p> <p>1. Situation In case of a break from the PC during the data connection to another modem:</p> <p>AT\K0 Modem enters the command mode and sends no break to the other modem</p> <p>AT\K1 Modem deletes the data buffer and sends a break to the other modem</p> <p>AT\K2 See AT\K1</p> <p>AT\K3 Modem immediately sends break to the other modem; data buffers are not deleted</p> <p>AT\K4 See AT\K0</p> <p>AT\K5 Modem inserts break into the data transmitted to the other modem</p> <p>2. Situation During a data connection, the modem was put into command mode by an escape sequence +++. In this condition, the command AT\B will send a break to the other modem. In this situation, the parameter n will cause the following:</p> <p>AT\K0 Modem deletes the data buffer and sends a break to the other modem</p> <p>AT\K1 See AT\K0</p> <p>AT\K2 Modem sends break to the other modem without delay</p> <p>AT\K3 See AT\K2</p> <p>AT\K4 Modem inserts break into the data transmitted to the other modem</p> <p>AT\K5 Like AT\K4 – Return from the online command mode into the data mode via the ATO command.</p> <p>3. Situation In the case a break is received from another modem during a connection that has not been error corrected, the parameters cause the following:</p> <p>AT\K0 Modem deletes the data buffer and sends a break to the PC</p> <p>AT\K1 See AT\K0</p> <p>AT\K2 Modem sends a break to the PC without delay</p> <p>AT\K3 See AT\K2</p> <p>AT\K4 Modem sends a break to the PC, which is embedded into the data that was received from the other modem</p> <p>AT\K5 Like AT\K4</p>

Command	Description
ATL<n>	<p><u>Speaker volume</u></p> <p>This command regulates the speaker volume (see ATM)</p> <p>ATL1 Speaker volume low (default)</p> <p>ATL2 Speaker volume medium</p> <p>ATL3 Speaker volume high</p> <p>Note: The speaker output is optional and is not supported in the standard version.</p>
AT*L<n>	<p><u>Determines the automatic speed limitation</u></p> <p>The automatic speed limitation is used to automatically achieve the least possible error rate for connections without error correction.</p> <p>In the factory settings the speed limitation is always switched on (AT*L0).</p> <p>If the limitation is switched off (AT*L1), the modem will always establish the connection on the phone side with the maximum possible speed (or the speed defined with AT+MS), irrespective of the data rate at the serial interface. This means that the INSYS Modem 336 will, for example, always attempt to establish a 33600-baud connection, even if the serial interface is only set to 9600 baud. Without error correction the high speed will obviously lead to higher bit error rates, which is usually disruptive.</p> <p>The automatic speed limitation (AT*L0) will limit the speed on the phone side to the speed of the serial interface.</p> <p>It should only be switched off if very low baud rates are employed or if the speed of the serial interface is changed during the connection.</p>
AT%L	<p><u>Display level of the received signal</u></p> <p>The value that is reported from the modem equals the already amplified level within the modem, not the phone line level.</p> <p>Large AT%L responses imply a low signal level; small values imply a high signal level (009 = -9db, 043 = -43db)</p>
ATM<n>	<p><u>Speaker control</u></p> <p>This command regulates when the speaker is active (see command ATL).</p> <p>ATM0 Speaker always OFF</p> <p>ATM1 Speaker ON during dialing and connection setup (default)</p> <p>ATM2 Speaker always ON</p> <p>ATM3 Speaker on during connection setup</p>

Command	Description																											
AT+MR=<n> <i>(only for INSYS Modem 56k)</i>	<u>Show modulation type</u> The command “ AT+MR “ enables the display of the modulation type after the message CONNECT AT+MR=0 switches the display function off (default). AT+MR=1 switches the display function on. The displayed value applies to the sent data AT+MR=2 switches the display function on. The displayed value applies to the received data If the display function is switched on the modem will display the modulation type and the line speed after the message CONNECT . After the message CONNECT , the line „ +MCR: ” appears, followed by the modulation type (see command AT+MS) and the line “ MRR: ”, followed by the line speed. The AT+MR command is useful for a connection check.																											
AT+MS=<n> <i>(only INSYS Modem 144/336)</i>	<u>Select modulation type</u> AT+MS determines the modulation type. The command enables or disables automatic modulation recognition and defines the highest and lowest possible connection speed. The command format is AT+MS=Modulation [Automode], [Send: Minbaud, Maxbaud], [μ-Law, A-Law], [reserved], [Sendspeed: Maxbaud] . AT+MS? Displays the current setting. AT+MS=? Displays a list of possible parameters Parameter modulation: The modulation parameter determines the preferred (automode = 1) or the mandatory (automode = 0) modulation type. The following values are available: <table><tr><td>0</td><td>V.21</td><td>300</td></tr><tr><td>1</td><td>V.22</td><td>1.200</td></tr><tr><td>2</td><td>V.22bis</td><td>2.400 or 1.200</td></tr><tr><td>3</td><td>V.23</td><td>1.200</td></tr><tr><td>9</td><td>V.32</td><td>9.600 or 4.800</td></tr><tr><td>10</td><td>V.32bis</td><td>14.400, 12.000, 9.600, 7.200 or 4.800</td></tr><tr><td>11</td><td>V.34</td><td>33.600, 31.200, 28.800, 26.400, 24.000, 21.600, 19.200, 16.800, 14.400, 12.000, 9.600, 7.200, 4.800 or 2.400</td></tr><tr><td>64</td><td>Bell 103</td><td>300</td></tr><tr><td>69</td><td>Bell 212</td><td>1.200</td></tr></table> Default factory setting: INSYS Modem 144 Value: 10 INSYS Modem 336 Value: 11	0	V.21	300	1	V.22	1.200	2	V.22bis	2.400 or 1.200	3	V.23	1.200	9	V.32	9.600 or 4.800	10	V.32bis	14.400, 12.000, 9.600, 7.200 or 4.800	11	V.34	33.600, 31.200, 28.800, 26.400, 24.000, 21.600, 19.200, 16.800, 14.400, 12.000, 9.600, 7.200, 4.800 or 2.400	64	Bell 103	300	69	Bell 212	1.200
0	V.21	300																										
1	V.22	1.200																										
2	V.22bis	2.400 or 1.200																										
3	V.23	1.200																										
9	V.32	9.600 or 4.800																										
10	V.32bis	14.400, 12.000, 9.600, 7.200 or 4.800																										
11	V.34	33.600, 31.200, 28.800, 26.400, 24.000, 21.600, 19.200, 16.800, 14.400, 12.000, 9.600, 7.200, 4.800 or 2.400																										
64	Bell 103	300																										
69	Bell 212	1.200																										

Command	Description
AT+MS=<n> <i>CONTINUATION</i>	<p>Parameter Automode: The optional parameter automode determines whether the modem automatically adjusts to the desired modulation type. The following values may be used:</p> <p>0 Automatic modulation adjustment switched off 1 Automatic modulation adjustment switched on</p> <p>Parameter Reception Minbaud: The optional parameter minbaud determines the lowest possible baud rate for modem reception.</p> <p>Parameter Reception Maxbaud The optional parameter maxbaud determines the highest possible baud rate for modem reception.</p> <p>Parameter μ-Law, A-Law ISND coding selection</p> <p>Parameter reserved = always 0</p> <p>Parameter Sendspeed Maxbaud The optional parameter maxbaud determines the highest possible baud rate for modem sending.</p> <p>Example: AT+MS=12,1,300,56000,0,0,33600 (automatically adjusted to the remote terminal; the minimum speed is 300 bps. The maximum reception speed is 56,000 bps, the maximum send speed is 33,600 bps).</p>
AT+MS=<n> <i>(only for INSYS Modem 56k)</i>	<p><u>Select modulation type</u></p> <p>AT+MS determines the modulation type. The command enables or disables automatic modulation recognition and defines the highest and lowest possible connection speed. The command format is AT+MS=Modulation, [Automode], [Send: Minbaud, Maxbaud]; [Reception: Minbaud, Maxbaud],</p> <p>AT+MS? Displays the current setting</p> <p>AT+MS=? Displays a list of possible parameters</p> <p>Default factory setting: depending on the device: V.90 or V92</p>

Command	Description																																					
AT+MS=<n> <i>CONTINUATION</i>	<p>Parameter modulation:</p> <p>The modulation parameter determines the preferred (automode = 1) or the mandatory (automode = 0) modulation type.</p> <p>The following values are available:</p> <table><tr><td>V21</td><td>V.21</td><td>300</td></tr><tr><td>V22</td><td>V.22</td><td>1200</td></tr><tr><td>V22B</td><td>V.22bis</td><td>2400 or 1200</td></tr><tr><td>V23C</td><td>V.23</td><td>1200</td></tr><tr><td>V32</td><td>V.32</td><td>9600 or 4800</td></tr><tr><td>V32B</td><td>V.32bis</td><td>14400, 12000, 9600, 7200 or 4800</td></tr><tr><td>V34</td><td>V.34</td><td>33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800 or 2400</td></tr><tr><td>V90</td><td>V.90</td><td>56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000</td></tr><tr><td>V92</td><td>V.92</td><td>56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000</td></tr><tr><td>B103</td><td>Bell 103</td><td>300</td></tr><tr><td>B212</td><td>Bell 212</td><td>1200/75</td></tr></table> <p>Parameter Automode:</p> <p>The optional parameter automode determines whether the modem automatically adjusts to the desired modulation type. The following values may be used:</p> <table><tr><td>0</td><td>Automatic modulation adjustment switched off</td></tr><tr><td>1</td><td>Automatic modulation adjustment switched on</td></tr></table> <p>Parameter Reception Minbaud:</p> <p>The optional parameter minbaud determines the lowest possible baud rate for modem reception.</p> <p>Parameter Reception Maxbaud:</p> <p>The optional parameter maxbaud determines the highest possible baud rate for modem reception.</p> <p>Parameter Send Minbaud:</p> <p>The optional parameter minbaud determines the lowest possible baud rate for modem sending.</p> <p>Parameter Send Maxbaud:</p> <p>The optional parameter maxbaud determines the highest possible baud rate for modem sending.</p>	V21	V.21	300	V22	V.22	1200	V22B	V.22bis	2400 or 1200	V23C	V.23	1200	V32	V.32	9600 or 4800	V32B	V.32bis	14400, 12000, 9600, 7200 or 4800	V34	V.34	33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800 or 2400	V90	V.90	56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000	V92	V.92	56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000	B103	Bell 103	300	B212	Bell 212	1200/75	0	Automatic modulation adjustment switched off	1	Automatic modulation adjustment switched on
V21	V.21	300																																				
V22	V.22	1200																																				
V22B	V.22bis	2400 or 1200																																				
V23C	V.23	1200																																				
V32	V.32	9600 or 4800																																				
V32B	V.32bis	14400, 12000, 9600, 7200 or 4800																																				
V34	V.34	33600, 31200, 28800, 26400, 24000, 21600, 19200, 16800, 14400, 12000, 9600, 7200, 4800 or 2400																																				
V90	V.90	56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000																																				
V92	V.92	56000, 54667, 53333, 52000, 50667, 49333, 48000, 46667, 48000, 46667, 45333, 42667, 41333, 40000, 38667, 37333, 36000, 34667, 33333, 32000, 30667, 29333, 28000																																				
B103	Bell 103	300																																				
B212	Bell 212	1200/75																																				
0	Automatic modulation adjustment switched off																																					
1	Automatic modulation adjustment switched on																																					

Command	Description
AT*M<n>	<p><u>Remote terminal selection</u></p> <p>Defines the protocol that is used to send the alarm string to the network provider.</p> <p>AT*M0 The remote terminal is a normal fixed network modem (default)</p> <p>AT*M1 The remote terminal is a mobile phone with network access via PET/IXO/TAP protocol and data format 8N1 (e.g. D1 and E networks in Germany)</p> <p>AT*M2 The remote terminal is a mobile phone with network access via EMI/UCP protocol and data format 7E1</p> <p>AT*M3 The remote terminal is a mobile phone with network access via PET/IXO/TAP protocol and data format 7E1</p> <p>AT*M4 The remote terminal is a mobile phone with network access via EMI/UCP and data format 8N1 (e.g. D2 network in Germany)</p> <p>AT*M5 The remote terminal is a fax machine</p> <p>AT*M6 Fixed network SMS: The SMS gateway (e.g. Deutsche Telekom via phone number 01930100) is not tied to a certain mobile phone network, but send SMS to any mobile or fixed network phone.</p> <p>Note: For the remote terminals AT*M1 to AT*M4, only recipients in the network of <i>one</i> GSM provider may be addressed.</p> <p>Your network provider will inform you about the current requirements to send SMS to mobile phones.</p> <p>Relevant commands: AT*V, AT*Vn Definition of messages/phone numbers</p> <p style="text-align: center;">AT*Z0 Definition of the SMS service center</p>
AT*N<n>=<nr> <i>(only for INSYS Modem 56k)</i>	<p><u>Permitted numbers for selective call acceptance</u></p> <p>Definition of 8 authorized phone numbers, for which modem access is permitted. Only if the transmitted phone number matches a phone number that was entered in the list will the modem report RING for an incoming call or will accept the call according to the settings in S0 (the line RI is activated with each call, irrespective of that fact). The selective call acceptance is switched on and off with AT&A.</p> <p>AT*N<n>=<nr></p> <p><n> describes the storage location – range of values: 0..7 .</p> <p><nr> permitted phone number consists of numbers and the wild card “*” for exactly one character. The phone number may not contain separators such as brackets or space characters. After they were entered, the phone numbers are immediately saved in the power fail-safe memory of the modem.</p> <p>AT*N99= deletes all existing entries in the list</p> <p>AT*N? displays all stored entries</p> <p>Example: AT*N0=01234567** permits all calls from the block of numbers 01234567-00 to 01234567-99</p>

Command	Description
AT*<i><N></i>99= (only for INSYS Modem 56k)	<u>Delete the list of permitted phone numbers for the selective call answer</u> The command AT*N99= deletes the entire list of phone numbers for the selective call answer.
AT*N? (only for INSYS Modem 56k)	<u>Output of the list of permitted phone numbers</u> AT*N? activates the output of the entire saved list of permitted phone numbers for the selective call answer.
AT%N (only for INSYS Modem 56k)	<u>Output of the last rejected phone number</u> For active selective call answer (AT&A1), the last phone number, whose call was rejected, will be displayed. This phone number is not saved in the power fail-safe memory of the modem.
AT\N<n>	<u>Select error correction</u> This command determines which type of error correction should preferably be used for subsequent connections. AT\N0 error correction switched off AT\N1 bit direct mode Transparent transmission of any data width via the serial interface without data buffering or error correction. The modem will evaluate the escape sequence (+++) up to 11-bit data width. AT\N2 Selects V.42LAP-M or MNP 4 error correction. If no error corrected connection can be established, the modem will hang up. AT\N3 Selects V.42LAP-M or MNP 4 error correction. If such a connection cannot be established, the modem will attempt to establish a connection that is not error corrected (default): AT\N4 Exclusively selects a V.42 LAP-M connection. AT\N5 Exclusively selects a MNP 4 connection.
ATO<n>	<u>Return to online data mode</u> If the modem is in online command mode, it will return to online data mode. If the modem is in offline command mode, it will report ERROR . ATO0 Return to online data mode ATO1 Before the modem switches to online data mode, a retrain procedure is provoked.
ATP	<u>Switch on pulse dialing method (deactivated for some models)</u> Starting with this command, each dial-up is performed with the pulse dialing method, until an ATT or ATDT command switches it back to tone dialing. On request, a version with pulse dialing is available for the INSYS Modem 14/336 – this version, however, is not authorized throughout Europe.
AT*P<n>	<u>Password query</u> AT*P0 switches the password query off after the connection has been established (default): AT*P1 switches the password query on after the connection has been established. If the password query is activated, the modem will query the password after CONNECT has taken place. After the password has been entered correctly, the actual CONNECT will take place and data may be transmitted. If a wrong password was entered, the modem will hang up. The password is the same as for remote control and is set with AT*C .

Command	Description
ATQ<n>	<u>Quiet control</u> This command toggles sending messages from the modem to the PC on and off. ATQ0 Send messages to PC (default) ATQ1 Don't send messages to PC
AT-Q<n> (only INSYS Modem 144/336)	<u>Fall back to V.22bis and V.22</u> AT-Q0 prohibits fall back to V.22bis and V.22 AT-Q1 enables fall back to V22bis or V.22 (default)
AT%Q	<u>Display telephone call quality</u> Displays the quality of the data connection (deviation from the eye diagram). Low values indicate a good line quality. The line quality value must be evaluated differently depending on the negotiated data rate. Connections with more than 9600 baud will reach the value "000" for good lines and should not have values of more than "010". For connections with 33600 baud good lines will have values between 010...030. Depending on the settings and the modulation type a fall back or retrain is triggered if the line quality is too bad to enable a new negotiation of the connection (if necessary with a slower speed). High values indicate bad quality. These values are constantly updated during a connection. If the value increases significantly during a connection, the quality will deteriorate. After a previous AT%E command, an <i>Autoretrain</i> is performed.
AT&R<n>	<u>RTS/ CTS behavior</u> This command determines how the modem treats the RTS/CTS (CT105/CT106) data flow control lines. (See also command AT&K). AT&R0 CTS behavior complies with V.25bis. CTS is deactivated during the connection setup after recognition of the response or ringing tones and will only be activated after the connection is set up. During the controlled half duplex operation (AT&K8) CTS is active, if the modem sends data at the serial interface. When data is received at the serial interface, CTS is inactive. AT&R1 CTS only switches to <i>off</i> when this is required by the data flow control. During the controlled half duplex operation (AT&K8) CTS is inactive, if the modem sends data at the serial interface. When data is received at the serial interface, CTS is active (default):
AT*R<n>	<u>Switches the remote control on and off</u> AT*R0 switches the remote control off AT*R1 switches the remote control on (default)

Command	Description
ATS<n>	<u>Read/write of the S registry</u> <p>Some S registries may only be modified within certain limits. The modem still reports OK although the value has not changed as specified. Certain registries are read-only. We recommend checking the results after each write attempt using the ATS<n>? command.</p> <p>ATS<n>=x Sets the S registry n to the value x.</p> <p>ATS<n>? Shows the value of the S registry n</p>
AT&S<n>	<u>DSR behavior</u> <p>This command determines how the modem treats its DSR (CT107) output.</p> <p>AT&S0 DSR always on (default)</p> <p>AT&S1 DSR <i>on</i> after a response tone has been detected; DSR <i>off</i> when no carrier is detected any more.</p>
AT*S<n>	<u>Selects the transmission speed at the serial interface.</u> <p>With this command the speed can be preselected. This will, however, not switch off the automatic detection. As soon as an AT is recognized, the serial interface will set itself to the recognized speed and protocol.</p> <p>If no AT is sent, the selected speed is maintained until a hardware reset is performed. If the selected speed should be maintained longer, it must be stored with AT&W.</p> <p>Attention: This command will not change the registry S23! It only changes if the automatic speed detection is used.</p> <p>AT*S0 maintain the current speed.</p> <p>AT*S1 300 bps</p> <p>AT*S2 600 bps</p> <p>AT*S3 1,200 bps</p> <p>AT*S4 2,400 bps</p> <p>AT*S5 4,800 bps</p> <p>AT*S6 9,600 bps</p> <p>AT*S7 19,200 bps</p> <p>AT*S8 38,400 bps</p> <p>AT*S9 57,600 bps</p> <p>AT*S10 115,200 bps (not INSYS Modem 144)</p>
AT%S<n>	<u>Ability to switch between DCD and DSR lines</u> <p>AT%S0 The DSR signal is on the DSR line The DCD signal is on the DCD line (Default factory setting)</p> <p>AT%S1 The DSR signal is on the DCD line The DCD signal is on the DSR line (Interchangeability of the lines)</p>

Command	Description																																								
ATT	<u>Switching on tone dialing</u> Starting with this command, each dial up is performed with the tone dialing method, until an ATP or ATDP command switches it back to pulse dialing.																																								
AT-TRV	<u>Phone Line Voltage Measurement (Tip Ring Voltage)</u> Use the command AT-TRV to measure the phone line voltage (Tip Ring Voltage). The result is yielded in volt. For an existing connection the voltage range will be 5V – 12V. Otherwise the voltage is higher than 20V. If the voltages are lower than 2V, no phone line is connected.																																								
AT*U<n>	<u>Selects the protocols at the serial interface.</u> With this command the protocol can be preselected. This will, however, not switch off the automatic detection. As soon as an AT is recognized, the serial interface will set itself to the recognized speed and protocol. If no AT is sent, the selected protocol is maintained until a hardware reset is performed. If the selected protocol should be maintained longer, it must be stored with AT&W . Attention: This command will not change the registry S23! It only changes if the automatic speed and protocol detection is used. <table><tr><td>AT*U0</td><td>8 data bits,</td><td>no parity,</td><td>1 stop bit</td></tr><tr><td>AT*U1</td><td>7 data bits,</td><td>odd parity,</td><td>1 stop bit</td></tr><tr><td>AT*U2</td><td>7 data bits,</td><td>even parity,</td><td>1 stop bit</td></tr><tr><td>AT*U3</td><td>7 data bits,</td><td>no parity,</td><td>1 stop bit</td></tr><tr><td>AT*U4</td><td>7 data bits,</td><td>odd parity,</td><td>2 stop bits</td></tr><tr><td>AT*U5</td><td>7 data bits,</td><td>even parity,</td><td>2 stop bits</td></tr><tr><td>AT*U6</td><td>7 data bits,</td><td>no parity,</td><td>2 stop bits</td></tr><tr><td>AT*U7</td><td>8 data bits,</td><td>odd parity,</td><td>1 stop bit</td></tr><tr><td>AT*U8</td><td>8 data bits,</td><td>even parity,</td><td>1 stop bit</td></tr><tr><td>AT*U9</td><td>8 data bits,</td><td>no parity,</td><td>2 stop bits</td></tr></table>	AT*U0	8 data bits,	no parity,	1 stop bit	AT*U1	7 data bits,	odd parity,	1 stop bit	AT*U2	7 data bits,	even parity,	1 stop bit	AT*U3	7 data bits,	no parity,	1 stop bit	AT*U4	7 data bits,	odd parity,	2 stop bits	AT*U5	7 data bits,	even parity,	2 stop bits	AT*U6	7 data bits,	no parity,	2 stop bits	AT*U7	8 data bits,	odd parity,	1 stop bit	AT*U8	8 data bits,	even parity,	1 stop bit	AT*U9	8 data bits,	no parity,	2 stop bits
AT*U0	8 data bits,	no parity,	1 stop bit																																						
AT*U1	7 data bits,	odd parity,	1 stop bit																																						
AT*U2	7 data bits,	even parity,	1 stop bit																																						
AT*U3	7 data bits,	no parity,	1 stop bit																																						
AT*U4	7 data bits,	odd parity,	2 stop bits																																						
AT*U5	7 data bits,	even parity,	2 stop bits																																						
AT*U6	7 data bits,	no parity,	2 stop bits																																						
AT*U7	8 data bits,	odd parity,	1 stop bit																																						
AT*U8	8 data bits,	even parity,	1 stop bit																																						
AT*U9	8 data bits,	no parity,	2 stop bits																																						
ATV<n>	<u>Format of modem messages</u> This command determines if the modem transmits messages to the PC in short or long format. <table><tr><td>ATV0</td><td>Messages to PC in short format, i.e. only the error number (default)</td></tr><tr><td>ATV1</td><td>Messages to PC in long form, i.e. the error text</td></tr></table>	ATV0	Messages to PC in short format, i.e. only the error number (default)	ATV1	Messages to PC in long form, i.e. the error text																																				
ATV0	Messages to PC in short format, i.e. only the error number (default)																																								
ATV1	Messages to PC in long form, i.e. the error text																																								
AT\V<n>	<u>Format of connect rate messages</u> This command enables the display of the connect message in one (\V1) line or in three lines (\V0) *.																																								

Command	Description
AT*V	<u>Definition of the common alarm texts (collective message)</u> for simple alarm: Definition of the alarm text (maximum of 160 characters) for pulse alarm: Definition of the common part of the alarm message (maximum of 160 characters – within HSComm limited to 120 characters) To the input AT*V the modem responds with NEW TEXT: and expects the input of the alarm text (completed with <CR>) This command is not available in the remote operation mode. Relevant commands: AT*V, AT*V<n> Definition of messages/phone numbers AT*Z0 Definition of the SMS service center
AT*V?	<u>Query of the common alarm texts (collective message)</u> The common part of the alarm message is queried with the command AT*V? .
AT*V<n>	<u>Definition of the variable alarm texts and phone numbers</u> Definition of the 10 variable alarm texts and phone numbers for the SMS dispatch for an input of n=1..10 pulses. The common part of the alarm message (Collective message) is defined with AT*V . After this command is activated, the modem will query the alarm text. To the input AT*V1 to AT*V10 the modem responds with NEW TEXT: and expects an input in the form phone number,message<CR> Phone number Enter without characters for accessing the exchange (only required for service number) Message Alarm message (maximum of 80 characters) For the transmission, the variable part (maximum of 80 characters) will be attached to the common part (maximum of 160 characters) of the collective message. Of the maximum of 240 characters, the first 160 characters are sent as SMS. This command is not available in the remote operation mode. Relevant commands: AT*V, AT*V<n> Definition of messages/phone numbers AT*Z0 Definition of the SMS service center
AT*V<n>?	<u>Query of the variable alarm texts and phone numbers</u> The variable part of the alarm message and the target phone number are queried with AT*V<n>?

Command	Description
AT&V<n>	<p><u>Display configurations</u></p> <p>AT&V0 The active configuration of the modem, the saved user defaults and the saved phone numbers 0 to 3 (the parameter 0 may be omitted) are displayed</p> <p>AT&V1 Displays the diagnostic data of the last connection (connection partner, reason for disconnect).</p> <p>TERMINATION REASON: Reason for termination. For example manually with the command ATH: "LOCAL REQUEST".</p> <p>LAST TX rate: Last baud rate at the phone line in send direction, prior to the termination.</p> <p>HIGHEST TX rate: Highest baud rate that was achieved at the phone line in send direction, prior to the termination.</p> <p>LAST RX rate: Last baud rate at the phone line in receive direction, prior to the termination.</p> <p>HIGHEST RX rate: Highest baud rate that was achieved at the phone line in receive direction, prior to the termination.</p> <p>Note: The data rates may vary if a fall forward, fall back or retrain occurred during the connection. To impact the negotiated data rate, use the command AT+MS.</p> <p>PROTOCOL: Displays the used error correction protocol. "LAPM" equals a V.42 secured connection. For "NONE", the connection was not error corrected (the error corrected can be influenced with the command AT\N).</p> <p>COMPRESSION: Displays the used data compression method. The example shows the used compression method V.42bis (the compression method can be set with the command AT%C).</p> <p>LINE QUALITY: Displays the quality of the data connection (deviation from the eye diagram). Low values indicate a good line quality. The line quality value must be evaluated differently depending on the negotiated data rate.</p> <p>Connections with more than 9600 baud will reach the value "000" for good lines and should not have values of more than "010".</p> <p>For connections with 33600 baud good lines will have values between 010..030. Depending on the settings and the modulation type a fall back or retrain is triggered if the line quality is too bad to enable a new negotiation of the connection (if necessary with a slower speed).</p> <p>Rx LEVEL: Displays the receive level (which is internally applied at the modem chip) in -dBm. High values indicate a low input level, low values indicate a high input level. The optimum receive levels range from approx. 012 to 028. Too high levels could cause distortions; too low levels will cause the line noise to have a negative impact on the connection quality.</p> <p>Local Rtrn Count: Number of retrains (renegotiation of the connection), triggered by the local modem.</p> <p>Remote Rtrn Count: Number of retrains (renegotiation of the connection), triggered by the remote modem.</p>

Command	Description
AT+VCID=<n> <i>(only for INSYS Modem 56k)</i>	<u>Set caller ID</u> With this function, the phone number of the caller can be displayed during an incoming call. (only for phone connections or phone units which support caller ID. If you want to use caller ID, please ask your network provider, if your connection supports caller ID) AT+VCID=0 switches the caller ID function off. (default) AT+VCID=1 switches the caller ID function on and displays the ID preformatted for incoming calls. AT+VCID=2 switches the caller ID function on and displays the ID unformatted for incoming calls.
AT+VRID=<n> <i>(only for INSYS Modem 56k)</i>	<u>Set last received caller ID</u> The command AT+VRID displays the caller ID of the last caller. AT+VRID=0 displays the ID preformatted. AT+VRID=1 displays the ID unformatted.
ATW<n>	<u>Error correction messages</u> This command determines which data transmission rate information is provided for a CONNECT message. ATW0 The modem reports the baud rate between modem and PC (default). ATW1 During the connection setup, the modem reports the phone line speed, the error correction protocol and the PC baud rate. ATW2 The modem reports the phone line speed.
AT&W<n>	<u>Save configuration</u> The command saves the current modem configuration including the S registry in one of the two user-defined defaults. AT&W0 Save in user default 0 AT&W1 Save in user default 1

Command	Description
ATX<n>	<p><u>Extended result messages, dial tone detection</u></p> <p>The command determines which group of messages the modem sends to the PC. This is important for PBXs, as often a leading 0 or 9 must be dialed before a dialing tone is heard on the line. <i>Blind dialing</i> (dialing without detecting the dialing tone) is activated or deactivated according to the parameter. The detection of the dialing tone, however, can always be enforced using the parameter W in the ATD dialing string (see command ATD). In the mode AT+FCLASS=1,2, the modem always sends the message CONNECT to the PC without specifying the transmission speed.</p> <p>ATX0 No detection of the dialing tone, i.e. an unsuccessful dialing attempt leads to the message NO CARRIER. No detection of the busy signal, i.e. when calling a busy line the message NO CARRIER is displayed. The message is displayed without specifying the speed.</p> <p>ATX1 As ATX0, but the CONNECT message contains the speed specification.</p> <p>ATX2 Dialing tone detection is active, i.e. a dialing attempt without the presence of a dialing tone leads to the message NO DIALTONE. No detection of the busy signal, i.e. when calling a busy line the message NO CARRIER is displayed.</p> <p>ATX3 No detection of the dialing tone, i.e. an unsuccessful dialing attempt leads to the message NO CARRIER. Busy signal detection active, i.e. when calling a busy line the message BUSY is displayed.</p> <p>ATX4 Dialing tone detection is active, i.e. a dialing attempt without the presence of a dialing tone leads to the message NO DIALTONE. (default) Busy signal detection is active, i.e. when calling a busy line the message BUSY is displayed.</p>
AT*X	<p><u>Terminate remote configuration</u></p> <p>The command AT*X terminates a remote configuration.</p>
ATY<n> <i>(only INSYS Modem 144/336)</i>	<p><u>Long-term interruption</u></p> <p>The command determines how the modem acts when it receives a long-term interruption (BREAK) or in which form the modem creates a long-term interruption.</p> <p>ATY0 No long-term interruption behavior (default)</p> <p>ATY1 Long-term interruption behavior active. For connections without error correction the modem sends a long-term interruption of four seconds before <i>hanging up</i>. The modem reacts to the reception of a long-term interruption (break longer than 1.6 seconds) by <i>hanging up</i>.</p>
AT&Y<n>	<p><u>Selection of user configuration for hardware reset</u></p> <p>AT&Y0 For a hardware reset following the AT&Y0-command, the user default 0 (created using the AT&W0 command) is loaded into the current modem configuration (default).</p> <p>AT&Y1 For a hardware reset following the AT&Y1-command, the user default 1 (created using the AT&W1 command) is loaded into the current modem configuration.</p>

Command	Description
AT*Yx,y	<u>Switch outputs</u> x: Port (OUT1=0, OUT2=1) If no port is specified (x), OUT1 is used y: Desired condition of the output (relay open =0, relay closed =1) Factory setting: AT*Y0,0 AT*Y1,0
ATZ<n>	<u>Software reset/load default</u> The command causes the modem to perform a software reset. The modem will load the default saved by the user (according to the parameter). If no parameter is specified, the user default 0 is loaded. ATZ0 Software reset; afterwards the user default 0 is loaded. ATZ1 Software reset; afterwards the user default 1 is loaded. Note: If the command is executed during an existing connection, the modem will terminate this existing connection and then execute the RESET!
AT&Z<n>	<u>Save phone numbers</u> The command saves four entries permanently in the EEPROM. Each entry may consist of up to 35 characters. The entries may be overwritten and must comply with the dialing string as described in the ATD command. AT&Z<n>=xxx n is the number of the list entry (from 0 to 3). xxx is the dialing string with the phone number. Layout of the alarm functions and security callback: AT&Z0=xxx Number of the modem or fax for a simple alarm message Service center number of the GSM provider for SMS access AT&Z1=xxx Enter the password into the modem that calls back AT&Z2=xxx Number of the mobile phone for simple alarm messages AT&Z3=xxx Number of the fax machine for collective alarm messages
<Pause> +++ <Pause>	<u>Change from data mode to command mode (online command mode).</u> 1 second pause before and after the entry, no <CR> . After the response OK, an additional waiting period of 1 second for the re-entering of AT commands must be observed.
<Pause> **** <Pause>	<u>Start of the remote configuration at the local modem</u> 1 second pause before and after the entry, no <CR> . After the response OK, an additional waiting period of 1 second for the re-entering of AT commands must be observed.

2 S Registry

S registries may be read and written using the **ATS** command. (See Chapter 5 “AT command set”, command **ATS**) Certain S registries may only be read; into others only a particular range of values may be entered.

If the range of values is exceeded, the modem will report **OK**, although the value was not accepted. We therefore recommend to immediately check the modifications by reading (**ATS<n>?**).

Note:

* These registries are stored in the user defaults with **AT&W0** or **AT&W1**.

2.1 Overview S Registry

Register	Function	Units	Range	Default
S0*	Number of ringing tones until automatically going off-hook	Ringing tones	0-5	5
S1	Ringing tone counter	Ringing tones	0-255	0
S2*	Escape	ASCII	0-255	43
S3	Return	ASCII	0-127	13
S4	Linefeed character	ASCII	0-127	10
S5	Backspace character	ASCII	0-255	8
S6*	Waiting period dial tone	s	4-7	4
S7*	Waiting period carrier signal	s	0-100	60
S8*	Dial tone delay	s	1-7	2
S9*	Reaction time carrier signal	0.1 s	1-255	6
S10*	Time period between lost carrier signal and hang up	0.1 s	20-254	20
S11*	Data Transmit Controller DTC (144/336)	1s	0-255	0
S12*	Transmission clock of the ESC characters	0.02 s	0-255	50
S13*	Number of dialing attempts to send the message		1-12	3
S14*	General settings			138
S15*	Data Transmit Controller DTC (56k)	1s	0-255	0**
S17*	Initial character for remote configuration		0-127	42
S21*	Settings for V24			116
S22*	Settings			75h (117)
S24*	Time period until switching into sleep mode	s	0-255	0
S25	Time period for DTR signal	0.01 s	0-255	5
S26	Time period between RTS/CTS	0.01 s	0-255	1
S27*	General settings	-		137

Register	Function	Units	Range	Default
S29	Time period for modifier “flash”	10 ms	17	17
S30	Time period until hang up due to silence	10 s	0-255	0
S31*	General settings	-		C2h (194)
S36*	Reset of error logs	-		135
S38	Time period until forced hang up	s	0-255	20
S39*	Flow control	-		3
S40*	General settings	-		104
S41*	General settings	-		195
S46*	Data Compression	-		138
S48*	Setting for V42 declaration phase	-		7
S86	Error event code	-		Read-only
S91*	Transmit Level	-	0-15	9
S95*	Result code	-		0

2.2 Description S Registry

S0* Rings to Auto Answer:

Number of rings until the modem goes off-hook

For S0=0 the modem will not go off-hook when a call comes in. The value of S0 can be between 0 and 5.

S1 Ring Counter

Counter for call ringing. S1 is read-only. S1 will be reset to zero when the modem answers a call.

S2* Escape Character

Escape character which causes a switch from data mode to online command input mode. Values larger than 127 will lead to the fact that no ESC character will be recognized.

S3 Carriage Return Character

Carriage Return Character

S4 Linefeed Character
Linefeed character

S5 Backspace Character
Backspace character

S6* Wait Time for Dial Tone (Before Blind Dialing)
Maximum waiting time for the dialing tone. After the modem went off-hook it waits 7 seconds for the dialing tone (fixed for approval purposes). If it detects a dialing tone during this waiting period it will start dialing. If no dialing tone is detected, it will check if the dialing tone detection has been activated or if the dial string (Chap. „AT Command Set“, command **ATD**) includes the parameter W. If the dialing tone detection is not active, the modem waits for the dialing tone. The waiting time is specified in S6.
The value of S6 can be between 4 and 7.

S7* Wait for Carrier
Wait for the carrier frequency from the other modem. The maximum time for the modem to wait for a response from the other modem is specified in S7. The time starts running as soon as the modem has finished dialing. The value of S7 can be between 0 and 180 seconds.

S8* Pause Time for Dial Delay Modifier
Dial pause time, if a comma is included in the dialing string. If a comma is included in the dialing string, the modem will wait during the dialing procedure until the time specified in S8 (in seconds) has run out. The value of S8 can be between 1 and 7 seconds.

S9* Carrier Detect Response Time
DCD response time for the carrier frequency from the other modem. The DCD output of the RS232 interface (CT109) of the modem switches to on, when the carrier frequency from the other modem is detected before the time defined in S9 (in tenth of seconds) runs out. S9 must be smaller than S10.

S10* Carrier Loss Disconnect Time
The time which leads to termination after carrier frequency loss. In S10, the time is specified in tenth of seconds, which the modem awaits to disconnect, if it can't detect the carrier frequency from the other modem anymore.

S11* DRC Time Settings (only for 144/336)

The idle connection control is a function integrated in the firmware which monitors the data transmission in online mode. This function prevents the modem to stay online for an unlimited amount of time, although no data is being transmitted anymore.

In the registry S15, any time period between 1 and 255 seconds may be entered. If S15 is set to 0, the idle connection control is switched off.

The timer will run immediately after the modem goes off-hook. As soon as the timer has run out, a modem reset is performed (which will forcibly lead to the hanging up of the modem).

S12* Escape Prompt Delay

Minimum pre and post run time and maximum interim time in tenth of seconds between two characters. This must be observed, if the modem is supposed to detect an abort sequence (usually +++).

S13* Number of dialing attempts to send the message

Bit	Meaning	
Bit 0-3	Number of dialing attempts	Range of values:1...12 Default value: 3 S13 determines the number of attempts to send the message. Note: The limitation to a maximum of 12 attempts is necessary for approval purposes (black listing).
Bit 4-7	Reserved	

S14* General Bitmapped Options Status – General settings

Bit	Meaning	
Bit 0	Reserved	
Bit 1	Echo on inputs	Command echo 0: Echo off 1: Echo on
Bit 2	Reserved	
Bit 3	Result format	Result codes: 0: Message numbers (ATV0) 1: Message texts (ATV1)
Bit 4	Reserved	
Bit 5	Tone/pulse dialing	Tone/pulse 0: Tone dialing (ATT) 1: Pulse dialing (ATP)
Bit 6	Reserved	
Bit 7	Originate/answer	Originate/answer 0: Answer mode 1: Originate mode

S15* DRC Time Settings (only for 56k)

The idle connection control is a function integrated in the firmware that monitors the data transmission in online mode. This function prevents the modem to stay online for an unlimited amount of time, although no data is being transmitted anymore.

In the registry S15, any time period between 1 and 255 seconds may be entered. If S15 is set to 0, the idle connection control is switched off.

The timer will run immediately after the modem goes off-hook. As soon as the timer has run out, a modem reset is performed (which will forcibly lead to the hanging up of the modem).

S17* Initial character for remote configuration

In S17, the ASCII code of a character which is used to start the remote configuration, is defined. Values >127 switch the remote configuration off completely. The default setting in S17 is "42", which equals the ASCII character "*". This means that the remote configuration is started with the Escape character sequence

<Pause> ** <Pause>.**

(Note: The number of characters in the Escape sequence is fixed to "4" characters).

S21* General Bitmapped Options Status – Settings for V24

Bit	Meaning	
Bit 0.1	Reserved	
Bit 2	CTS behavior	CT106 (CTS) behavior: 0: see AT\K0 1: see AT&R1
Bit 3-4	DTR behavior	CT108 (DTR) behavior: 0: see AT&D0 1: see AT&D1 2: see AT&D2 3: see AT&D3
Bit 5	DCD behavior	CT109 (DCD) behavior: 0: see AT&C0 1: see AT&C1
Bit 6	DSR behavior	CT107 (DCD) behavior: 0: see AT&S0 1: see AT&S1
Bit 7	Long-term interruption	Long space disconnect: 0: see ATY0 1: see ATY1

S22* Bitmapped Options Status

Bit	Meaning	
Bit 0.1	Speaker volume	Speaker volume: 0: Off (ATL0) 1: Silent (ATL1) 2: Medium (ATL2) 3: Loud (ATL3)
Bit 2-3	Speaker control	Speaker control: 0: Off (ATM0) 1: On until carrier (ATM1) 2: Always on (ATM2) 3: On at establishing (ATM3)
Bit 4-6	Error message group	Limit result codes: 0: see ATX0 4: see ATX1 5: see ATX2 6: see ATX3 7: see ATX4
Bit 7	Stores the setting of AT*L	

S24* Sleep Timer:

The time after which the modem switches to energy saving mode (sleep) during inactivity is determined (in seconds) in S24. The energy saving mode will be quit as soon as characters are sent to the modem, or when a call comes in.

Note: The first “AT” ends the sleep mode, but is not recognized positively. When the modem is in sleep mode, it is necessary to send an “AT” command before sending other commands. This first “AT” command may not be answered with “OK”.

S25 Delay to DTR Off:

Time period, in which a DTR signal is applied to the modem before it hangs up (in hundreds of seconds).

S26 RTS to CTS Delay

Time period between RTS and CTS activation in 1/100 seconds.

S27* General Bitmapped Options Status – General settings

Bit	Meaning	
Bit 0-3	RS232-Mode	Asynchronous Mode Selection: 0: see AT&M0 or AT&Q0 9: see AT&Q5 10: see AT&Q6
Bit 4.5	Reserved	
Bit 6	CCITT or Bell Modulation	CCITT/Bell Select 0: CCITT Modulation 1: Bell Modulation
Bit 7		Remote control 0: Remote control off 1: Remote control on

S29 Flash Dial Modifier Time:

Sets the time period in tenths of seconds, after which the modem hangs up due to a flash in the dialing string.

S30 Disconnect Inactivity Timer:

Time period, in which the modem waits without activity before hanging up. Units in seconds (only for FAX Class 1).

S31* General Bitmapped Options Status – General settings

Bit	Meaning	
Bit 0		
Bit 1	Description Connect message	0: 3-line message (\V0) 1: Expanded 1-line message (\V1)
	Error correction Messages	Messages: 0: Only PC baud rate 1: PC and phone baud rate (ATW1) 2: Only phone baud rate (ATW2)
Bit 4-7	Reserved	

S36* LAPM Failure Control

Bit	Meaning	
Bit 0..2	Determines what happens if an attempt to establish a V.42 LAP-M connection fails. It is connected to the registry S48.	0 Modem hangs up 1 Modem stays online and establishes a direct mode connection. 2 Reserved 3 Modem stays online and establishes a direct mode connection. 4 Modem attempts to establish a MNP connection. In case of failure it hangs up. 5 Modem attempts to establish a MNP connection. In case of failure a direct mode connection is established. 6 Reserved 7 Modem attempts to establish a MNP connection. In case of failure a normal mode connection is established.
Bit 3..4	SMS type	0: normal fixed network modem (AT*M0) 1: D1 and E networks (AT*M1) 2: D2 network (AT*M4) 5: Fax (AT*M5)
Bit 6	Key abort	0: Key abort activated 1: Key abort deactivated
Bit 7		1: Call answer not locked (AT*A1) 0: Call answer locked (AT*A0)

S38 Delay Before Forced Hang-up

Maximum time left for the buffers to empty their data, after a command to hang up has been received. Only applies to error corrected connections.

S39* PC / Flow Control Modem

Selection of the data flow control between the PC and the modem

S39=0 No data flow control (**AT&K0**)

S39=3 RTS/ CTS data flow control (**AT&K3**)

S39=4 XON/ XOFF data flow control (**AT&K4**)

S39=5 Transparent XON data flow control (**AT&K5**)

S39=6 RTS/CTS and XON/XOFF data flow control

S40* General Bitmapped Options Status – General settings

Bit	Meaning	
Bit 0	Reserved	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3-5	Break handling	Break handling 0: see AT\K0 1: see AT\K1 2: see AT\K2 3: see AT\K3 4: see AT\K4 5: see AT\K5
Bit 6-7	MNP block size	MNP block size 0: 64 characters (AT\A0) 1: 128 characters (AT\A1) 2: 192 characters (AT\A2) 3: 256 characters (AT\A3)

S41* General Bitmapped Options Status – General settings

Bit	Meaning	
Bit 0.1	Select compression type	Compression Selection 0: No compression (AT%C0) 1: MNP5 (AT%C1) 2: V42bis (AT%C2) 3: MNP5 or V.42bis (AT%C3)
Bit 2	Auto retrain	Auto retrain control 0: No auto retrain (AT%E0) 1: Auto retrain (AT%E1)
Bit 3	Reserved	
Bit 4	MNP block mode reserved for 56k models	Block Mode Control MNP 0: reserved 1: Block mode (AT\L1)
Bit 5	Reserved	
Bit 6	Fall back/fall forward	FB/FF control 0: No FB/FF 1: FB/FF (AT%E2)
Bit 7	Reserved	

S46* V.42bis Data Compression

S46=136 No data compression

S46=138 V.42bis data compression on

S48* V.42 Negotiation Control – V.42bis Connection Setup Protocol

S48=0 Only LAPM connection possible

S48=7 LAPM or MNP 4 connection

S48=128 Connection protocol as laid down in S36

S86 Call Failure Reason Code

When a connection fails (NO CARRIER) an event code is written into this registry.

S86=0	Normal disconnect, no error
S86=4	Carrier lost
S86=5	No error corrected (V.42) connection could be established
S86=6	No extensions could be negotiated
S86=7	Remote terminal only supports synchronous modems
S86=8	No joint framing detected
S86=9	No protocol could be established
S86=10	Invalid answer when negotiating extensions
S86=11	No synchronous marks received from remote terminal
S86=12	Normal disconnection by remote terminal
S86=13	Remote terminal didn't respond any more (ten attempts)
S86=14	Protocol error
S86=15	DTR drop
S86=16	Remote terminal demanded cleardown (GSTN cleardown)
S86=17	Inactivity timer expired
S86=18	Desired speed is not supported
S86=19	Long space disconnect
S86=20	Key abort (character was sent during connection setup)
S86=22	No connection setup possible
S86=23	Cleardown after 3 retrains
S86=26	Remote terminal hung up

S91* Transmit Level

The value for the transmit level of the modem is stored in the S91 registry. The value can be set between 0 and 15. The connection can in some cases be improved by decreasing the transmit level.

S91=0	Transmit level – 1 dBm
S91=15	Transmit level – 16dBm

Note: The range and the default value depend on the country settings (**AT+GCI**).

S95* Result Code Control – Result code

Bit	Meaning
Bit 0	CONNECT message with line speed
Bit 1	CONNECT/ARO message for error corrected connection
Bit 2	CARRIER messages enabled (messages 40 – 47)
Bit 3	PROTOCOL messages enabled (messages 70 – 80)
Bit 4	Reserved
Bit 5	COMPRESSION message enabled (messages 66 - 69)
Bit 6	Reserved
Bit 7	Reserved

3 Country Codes (only 56k)

The standard TBR21 applies to all public phone networks in EU countries (Belgium, Denmark, German, Finland, France, Greece, Great Britain, Ireland, Italy, Luxembourg, Netherlands, Austria, Portugal, Sweden, Spain), as well as in Switzerland, Liechtenstein, Norway and Iceland. Only old telecommunications systems require an explicit setting of the individual country.

3.1 Version for Standard Countries

Country	Country code	Country	Country code
TBR21	FD (default)		
Belgium	0F	Mexico	73
Brazil	16	Netherlands	7B
China	26	Norway	82
Denmark	31	Austria	0A
Germany	42	Poland	8A
Finland	3C	Portugal	8B
France	3D	Romania	8E
Greece	46	Saudi Arabia	98
Great Britain	B4	Sweden	A5
India	53	Switzerland	A6
Ireland	57	Slovak Republic	FB
Iceland	52	Slovenia	FC
Italy	59	Spain	A0
ITU/Taiwan	FE	Czech Republic	2E
Japan	00	Turkey	AE
Canada	20	Hungary	51
Kuwait	62		

3.2 Version for Extended Country Group

Country	Country code	Country	Country code
TBR21	FD (default)	Kuwait	62
Egypt	36	Lebanon	64
Argentina	07	Malaysia	6C
Belgium	0F	New Zealand	7E
Brazil	16	Nigeria	81
Bulgaria	1B	Pakistan	84
Chile	25	Panama	85
China	26	Paraguay	87
Dominican Republic	33	Philippines	89
Estonia	F9	Russian Federation	B8
Hong Kong	50	Senegal	99
India	53	Singapore	9C
Indonesia	54	Sri Lanka	A1
Israel	58	South Africa	9F
Japan	00	Uruguay	B7
Colombia	27	Venezuela	BB
Republic of Korea	61	United Arab Emirates	B3
Croatia	FA	Cyprus	2D

3.3 Country Codes for Both Versions

Country	Country code	Country	Country code	Country	Country code
Australia	09	Honduras	FE	Oman	FE
Algeria	FE	Yemen	FE	Peru	FE
Bolivia	FE	Jordan	FE	Thailand	A9
Bosnia Herzegovina	FE	ITU/Taiwan	FE	Tunisia	FE
Brunei	FE	Liechtenstein	FD	Ukraine	FE
Costa Rica	FE	Latvia	FD	USA	B5
Ecuador	FE	Lithuania	FE	Belarus	FE
El Salvador	FE	Morocco	FE		
Guatemala	FE	Nicaragua	FE		

Space for Comments: